




## STEP ①

**Remove your existing AC Vent**



## STEP ②

**Measure the inside of the duct opening in Inches**

If the inside measurement of your duct is 12"x6", then you order a 12"x6" vent



## STEP ③

**Replace your vent**

Note: In the example above of a 12"x6',  
The neck of the AC vent will be smaller than 12"x6", - and the face will be bigger than 12"x6"